


QUICK INSTALLATION GUIDE

Three-phase ESS Inverter


12kW/15kW/20kW/25kW/30kW

1 PACKING LIST




- A. Inverter
B. File package
C. PV connector group
D. Battery connector group
E. AC waterproof cover
F. Insulation board for AC terminal
G. M5 Screw cap
H. OT terminal
I. Mounting bracket
J. M10 Expansion blot
K. M6 Security screw
L. 3-Pin terminal
M. 4-Pin terminal
N. 6-Pin terminal
O. 9-Pin terminal
P. Pin terminal
Q. CT pack
R. Tightening/Removal tool for PV connector
S. WIFI/LAN module
T. Battery temperature sensor
U. Meter

2 LOCATION




3 INSTALLATION

- The installation walls must be fireproof and non-flammable materials, otherwise there is a fire risk.
 - Before drilling holes, check whether there are electric power pipes or other pipes buried in the walls to avoid risks.
- The inverter is heavy! To avoid device damage and personnel injury, at least two people are recommended to move the inverter and handle with care.




4 GROUNDING

Ensure that the inverter and all cables to be installed have been completely powered off during the whole process of installation and connection. Otherwise, high voltage may result in fatal injury.




5 WIRING SYSTEM



Ensure that the inverter and all cables to be installed have been completely powered off during the whole process of installation and connection. Otherwise, high voltage may result in fatal injury.






6 WIRING SYSTEM

Ensure that the inverter and all cables to be installed have been completely powered off during the whole process of installation and connection. Otherwise, high voltage may result in fatal injury.









* Meter communication cable can be connected to any inverter of the parallel system and this inverter will be inverter No. 1.




Note:
It is recommended to use outdoor dedicated cables with multiple copper cores.




Note:
PV cable should be dedicated PV cable
(suggest using 4-6mm² PV1-F cable).




4 Tighten the waterproof nuts.





5 Ensure that the PV switch is OFF.




- 4 Test string voltage and confirm string polarity.



6 Insert the positive and negative connectors into the PV+/PV- ports until a "click" sound is heard.




NOTE	12K/15K/20K:support BAT1 only; 25K/30K: support BAT1 and BAT2.
--	--




Note: choose the proper connector parts according to the BAT cable cross section (S).

BAT Cable Item (recommendation)	Spec 1	Spec 2
Diameter(D)	6.5~7.5 mm	8.0~9.0 mm
Cross section(S)	10 mm ²	16 mm ²
Strip length (L)	~10mm	
Cable total length	≤ 3m	


Note: the 10mm² BAT cable is applicable to 12K/15K/20K, while the 16mm² BAT cable is applicable to all inverter models.




Note: battery DC breakers are not supplied with the inverter.




Warning!
Reverse polarity will damage the inverter!

 **NOTE** For details, please refer to the corresponding Module Installation Guide in the packing.
The appearance of modules may be slightly different. The figure shown here is only for illustration.



- 1 Unscrew and remove the cover.
- 2 Insert WiFi / LAN module into the port firmly.

Note:
Proper strength to avoid damage to the module.



- Secure the module.

12 COMMUNICATION Cable(s) Connection

① Unscrew the waterproof cover.
② Loosen the nut on waterproof cover.
③ Remove sealing plugs.

1

PIN-terminal
8.0mm → 7.5±0.5 mm

Note:
The recommended wire size: 0.2~0.5mm².

② Wires crimping.

③ Thread the communication cable(s) through the nut, seal and waterproof cover in turn.

Don't cut off any communication cables.
Press the communication cables in the seal via the side incisions.

Another inverter side

CT

Lithium Battery

Meter / Upper computer

Waterproof cover

PARAL 4-Pin Terminal

PIN	Description
1	GND_S
2	PARA_SYNC
3	CAN_L
4	CAN_H

CT 6-Pin Terminal

PIN	Description	Color
1	CT3- (L3)	Black
2	CT3+ (L3)	/
3	CT2- (L2)	Black
4	CT2+ (L2)	/
5	CT1- (L1)	Black
6	CT1+ (L1)	/

BMS 12345678

PIN	Description
1	RS485_A
2	RS485_B
3	GND
4	CAN_H
5	CAN_L
6	NC
7	NC
8	NC

RS485 6-Pin Terminal

PIN	Description
1	RS485 A1 (for Monitoring)
2	RS485 B1 (for Monitoring)
3	RS485 A1 (for Monitoring)
4	RS485 B1 (for Monitoring)
5	RS485 A2 (for Meter)
6	RS485 B2 (for Meter)

④ Assemble the RJ45/ 4-pin / 6-pin terminals according to each Pin definition as needed.

⑤ Install the seal into the threaded sleeve, fasten the rubber nut.

1.2N·m

13 STARTUP/SHUTDOWN PROCEDURE

Inspection

No.	Items
1	The inverter is firmly installed.
2	There is enough heat dissipation space, no external objects or parts left on the inverter.
3	It is convenient for operation and maintenance.
4	The wiring of the system is correct and firm.
5	Check whether the DC and AC connections are correct with a multimeter, and ensure that there is no short circuit, break, or wrong connection.
6	Check whether the waterproof nuts of each part are tightened.
7	The vacant ports have been sealed. All gaps at the cable inlet and outlet holes have been plugged with fireproof/waterproof materials, such as fireproof mud.
8	All safety labels and warning labels on the inverter are complete and without occlusion or alteration.

Startup Procedure

① PV Switch 'ON'

② Battery Circuit Breaker 'ON'

③ AC Circuit Breaker 'ON'

④ Go to APP; finish Quick Setup; and start the inverter.

⑤ BACKUP Circuit Breaker 'ON'

Note: if Backup loads are inductive or capacitive loads which have high start-up current, please make sure the inverter is powered on successfully before turning on the BACKUP circuit breaker.

Shutdown Procedure

⚠ After the inverter is powered off, the remaining electricity and heat may still cause electric shock and body burns. If you need to disconnect the inverter cables, please wait at least 10 minutes before touching these parts of inverter.

① Go to APP; enter Quick Setup; and shutdown the inverter.

② PV Switch 'OFF'

③ AC Circuit Breaker 'OFF'

④ Battery Circuit Breaker 'OFF'

⑤ BACKUP Circuit Breaker 'OFF'

14 DISPLAY

LED	Status	Description
PV	On	PV input is normal.
	Blink	PV input is abnormal.
	Off	PV is unavailable.
BAT	On	Battery is charging.
	Blink	Battery is discharging. Battery is abnormal.
	Off	Battery is unavailable.
GRID	On	GRID is available and normal.
	Blink	GRID is available but abnormal.
	Off	GRID is unavailable.
BACKUP	On	BACKUP power is available.
	Blink	BACKUP output is abnormal.
	Off	BACKUP power is unavailable.
COM	Blink	Data are communicating.
	Off	No data transmission.
ALARM	On	Fault has occurred and inverter shuts down.
	Blink	Alarms have occurred but inverter doesn't shut down.
	Off	No fault.